



TEAK WONDER

SOME QUESTIONS ANSWERED

THIS IS A HELP AND ADVICE SHEET ONLY FOR ANYBODY INTENDING TO USE TEAK WONDER PRODUCTS. ALWAYS READ THE MANUFACTURERS INSTRUCTIONS ON THE LABEL.

Teak Wonder is a chemical process and therefore should only be used by competent adults. **KEEP OUT OF REACH OF CHILDREN AND ANIMALS.** Always wear suitable clothing, eg, old waterproofs, deck boots and suitable hand and eye protection. If in doubt ask your supplier.

Teak Wonder is designed for use with teak but can be used on a whole range of hardwoods. Always test the product in advance on a small area to your satisfaction before you use it on the main area.

Teak Wonder is designed for external wood use only and is not recommended for internal use, ie, hardwood floorboards. If applying the product inside always allow adequate ventilation.

ALWAYS READ THE INSTRUCTIONS ON THE LABEL IN CONJUNCTION WITH THIS ADVICE.

One: CLEANER. Always soak the timber with plenty of water before starting, do not let it dry out during cleaning, and add small amounts of water if necessary. Use a large soft deck brush, but do not try to do too big an area at once, work on one area at a time.

Start at the bow of the boat and move aft slowly, work at an even rate then wash down the deck again after each area has been cleaned.

Clean the whole deck, wash down then go back and tackle any stubborn or very dirty areas again. Keep cleaning the area until soapy residue no longer gets dirty or goes brown. Use a bucket or small container and apply cleaner with a small brush to these areas. Allow it to soak in, scrub, and then rinse away.

Always scrub across the grain where possible and always use a soft brush to avoid damaging the timber.

Two: BRIGHTENER. Apply directly from container only. Apply to wet teak deck area that has been previously cleaned with Teak Wonder Cleaner. Brighten a small area at a time, rinse with plenty of water and do not allow prolonged contact with other surfaces. Follow manufacturer's instructions on the container.

Three: DRESSING SEALER. This is the best bit! To avoid having to clean and brighten the deck on a regular basis apply Teak Wonder Dressing Sealer. Its not an oil or a varnish and does not suffer from the problems that these products can create on teak. Hopefully by now you will be very pleased with the results from the cleaner and brightener products, so give the sealer a try.

We know over the years that the general yachtsperson has been persuaded to use all sorts of new products and have suffered patchy, stained or damaged timber as a result. Teak Wonder has been used by many boatbuilders and yacht owners for over twenty years around the world and has a very loyal following. If you are really worried about it try the sealer first on a small area like the auxiliary outboard bracket or the coach roof hand rails and leave it for a few weeks to see the results.

THE TEAK MUST BE COMPLETELY DRY BEFORE APPLYING SEALER.

The Dressing Sealer is of a very thinly diluted solution so should be applied carefully with a suitable brush or application pad. Stir well both before and during application. If possible, pour sealer into another suitable large container to make sure that it can be properly stirred.

If applying to timber that has previously been treated with another product (other than Teak Wonder), try a small test area or talk to our Technical Department first. Wipe away any excess from other materials such as GRP immediately.

TEAK WONDER SHOULD NOT HARM MOST MARINE PAINTS, VARNISHES OR FIBREGLASS. HOWEVER, DUE TO VARIED FORMULAS OF PAINTS, VARNISHES, ETC THE MANUFACTURER OF THIS PRODUCT RECOMMENDS AVOIDING CONTACT WITH THESE SURFACES TO PREVENT ANY POSSIBLE DAMAGE.