

Part	Part Number	Description	Web Catagery
78	ENS59992	Medium Enam Burner Cap Defendi 3	Burner parts
77	ENS59998	Medium Flame Spreader For Burner Defendi 3 With Ign Hole	Burner parts
76	ENS59995	Medium Cup For Burner Defendi 3 With Ignition Hole	Burner parts
70	ENS59993	Large Enam Burner Cap Defendi 3	Burner parts
69	ENS59997	Large Flame Spreader For Burner Defendi 3 With Ign Hole	Burner parts
68	ENS59996	Large Cup For Burner Defendi 3 With Ignition Hole .80 Jet	Burner parts
82	ENS64020	Oven Burner For Eno Requires Ens83203361 Not Included	Burner parts
81	ENS83203361	Air Shutter Ring For The End Of Eno Oven Burner S/S	Burner parts
79	ENS58263	Gas Jet 0.67 Eno Med Defendi Burner	Burner parts
73	ENS58264	Gas Jet 0.80 Eno Large Defendi Burner	Burner parts
17	ENS52265	Gas Jet Eno 0.58 Grill Gascogne/Grand Large	Burner parts
112	ENS60001	Small Flame Spreader For Burner Defendi 3 With Ignition Hole	Burner parts
113	ENS59991	Small Enam Burner Cap Defendi 3	Burner parts
11	ENS60000	Small Cup For Bumer Defendi 3 With Ignition Hole	Burner parts
128	ENS71541	Grill Burner	Burner parts
25	ENS11204123	Side Frame & Outer Glass ENO ONE	Door parts
24	ENS71344	Eno Oven Door Seal Clip In Type	Door parts
58	ENS51341	Door Closing Spring For Eno Oven Door	Door parts
131	ENS55927	Door Glass Inner For Eno Extruded Door all 2001 onwards	Door parts
12	ENS61051	Gimble plate and	External parts
8	ENS71268	Rubber Protection Cover For Anti Gimbal Bolt	External parts
45	ENS14204140	Hob Heat Shield (Gascogne/Open Sea & Eno One)	External parts
133	ENS64030	Door Handle S/S Grand Large/Bretagne/Perigord	External parts
34	ENS71571	Top Grid Clamp For Eno Hob	External parts/ Pan clamps
30	ENS63363	Top Grid/Pan Support S/S 3 Burn all eno 200 onwards	External parts/ Pan clamps
74	ENS72648	Ignition Spark Probe For Eno Hob Defendi L650Mm	Ignition system
90	ENS72645	Electronic Ignition Box 4 Way Eno	Ignition system
91	ENS72646	Push Button For Electronic Ignition Series P	Ignition system
92	ENS72647	ENO & F10 Battery Holder For Electronic Ignition AA 1.5 Volt	Ignition system
78/59	ENS72671	Ignition Spark Probe For Eno Oven / Grill L1100Mm & Plancha	Ignition system
36	ENS55036	Knob For Pan Holder Black M3	Knobs
14	ENS55026	Knob Chrome For Eno Top Burner & Grill	Knobs
14	ENS55027	Knob Chrome For Eno Oven (Thermostatic Option Only)	Knobs
28	ENS63359	Oven Grid Stainless For Eno Ovens	Oven shelving
27	ENS4200029	S/S Oven Bottom Plate For all Eno	Oven shelving
26	ENS63355	Oven Side Rack Drop In For 5 Eno Oven Stainless	Oven shelving
29	ENS04200026	Drip Tray Stainless Steel For Eno Oven	Oven shelving
99	ENS63622	122Mm Pan Holder (Rail/Centre) Left Hand 226Mm Over All	Pan clamps
101	ENS63623	122Mm Pan Holder (Rail/Centre) Right Hand 226Mm Over All	Pan clamps
18	ENS55027	Knob Chrome For Eno Top Burner & Grill	Knobs
83/78	ENS70655	Thermocouple For Oven Burner Eno (1100Mm)	Thermocouples
72	ENS71416	S/S Clip For Thermocouple, Top Burner Eno (350Mm)	Thermocouples
71	ENS71415	Thermocouple For Top Burner Eno (350Mm) Defendi Burner	Thermocouples
19	ENS61038	Saddle/Bracket For Ens72110 Eno Gas Valve	Valves
17	ENS57023	Fixing Nut For Gas Valve Ens72110/ Ens72123	Valves
16	ENS72110	Hob/Oven Gas Valve For Eno Gas/Grand Large/One/ No Grill	Valves
13	ENS72117	Oven Thermostatic Gas Valve Bretagne (Thermo Option Only)	Valves
13	ENS72123	Oven/Grill Gas Valve Non Thermo Sabaf 2006 Onwards	Valves

Generic Parts Diagram Eno 3 or 4 Burner Grill With Oven

Click on the table above for link to parts.
Check all parts on individual webpages for correct specification for your
Eno. "Parts subject to change"

